



Paint Over Wallpaper QuickTip

What you need:

1. paint roller
2. step ladder
3. bucket of white pigmented shellac (get more buckets as needed)
4. paint roller pan

How to do it:

1. Open shellac can and pour shellac into roller pan
2. Roll paint roller in pan until well coated with shellac.
3. Roll shellac with roller onto wall. Get a solid, even coat. It's ok if the wallpaper bleeds through the shellac.
4. Let dry for an hour. Then continue with painting over your wallpaper.