



## ***Refinishing Cabinets and Woodwork QuickTip***

### What you need:

1. Mineral Spirits (paint thinner)
2. Boiled Linseed Oil (Purchased as Boiled Linseed Oil)
3. #0000 Steel Wool
4. Clean rags (preferably soft cotton)

### How to do it:

1. Mix one part linseed oil with two parts mineral spirits.
2. Saturate a hand-size piece of #0000 steel wool in this mixture and rub lightly, making certain to follow the grain pattern.
3. Then, take the clean rags and wipe off the excess.
4. Apply the mesh drywall tape along each edge of the drywall square.
5. If the area you have just treated feels sticky, put a dab or two of mineral spirits on a fresh clean cloth and wipe the area down to remove the excess linseed oil. If the mixture starts to thicken, add some mineral spirits.

**DO NOT USE RAGS TO APPLY, AS IT WILL SEPARATE. IF YOU DO HAVE A RAG WITH THIS MIXTURE ON IT, FIRST SOAK IN WATER AND DISPOSE IN ZIP LOCK BAG, AS IT MAY INSTANTANEOUSLY COMBUST.**